

EGB-200P and EGB-300P

Governor/Actuator

Application

The EGB-200P/-300P Governor/Actuator is used with Woodward electronic governors that produce a 20–160 mA control signal on dual fuel, diesel and gasoline engines, and steam turbines driving alternators, generators, pumps, or compressors.

Description

The EGB-200P/-300P is a governor/actuator providing the electronic governor with 200/300 lb-ft (270/400 N·m) work capacity for positioning the engine or turbine fuel racks or linkage.

The EGB-200P/-300P is a completely self-contained governor/actuator for use with large engines or turbines which require high output governors.

Upon loss of electric control signals, the standard EGB-200P/-300P is adjusted to cause engine or turbine shutdown. The addition of an optional starting device allows prime mover starting and operation under ballhead control. The ballhead section will also regulate fuel if the control fails in such a manner as to call for maximum fuel.


The EGB-200P/-300P can be factory set for a reverse-acting control to give maximum fuel upon loss of electric governor control signal.

The electric actuator section will respond to isochronous or droop governor control. Speed and droop adjustments for the electric actuator are made through the electric governor control system. If the control and EGB-200P/-300P are paralleled to an infinite bus or to other unlike governors, the droop mode must be used.

The EGB-200P/-300P ballhead section may operate isochronously for single unit application. A droop adjustment knob on the front panel provides droop adjustment for the ballhead governor in parallel application.

The load limit control knob is used to adjust the maximum output position of the EGB200P/-300P. The knob may be used to manually shut down the engine or turbine.

A high output booster servomotor may be used to help move the governor output toward the maximum fuel position before starting the engine or turbine.



- Electric hydraulic actuator
- Backup ballhead governor
- Single or parallel operation in droop or isochronous modes
- 200/300 lb-ft (270/400 N·m) output
- Self-contained oil supply

Installation

Governor Output

200 lb-ft (270 N·m) 300 lb-ft (400 N·m)

Stalled Torque Mid Travel Mid Travel

275 lb-ft (373 N·m) 490 lb-ft (664 N·m)
Rated Work 172 lb-ft (233 N·m) 306 lb-ft (415 N·m)
Useful Work 115 lb-ft (156 N·m) 204 lb-ft (277 N·m)

Terminal Shaft 1/8"-48 SAE serration. Shaft may extend from either side.

Terminal Shaft Travel 40 degree maximum travel. Use approximately 27 degrees travel between

no load and full fuel. Relationship between engine torque output and rotary

terminal shaft travel must be approximately linear.

Governor Drive

Speed Range 300 to 1200 rpm. 900 to 1100 rpm recommended drive speed. 300 to 1200

rpm operating range.

Rotation clockwise, counterclockwise, or both

Drive Requirements 2.5 hp (1.9 kW) to turn drive shaft at rated speed at normal operating

temperature. 1 1/8-48 serration solid drive shaft is standard. Keyed and

nonstandard serration shafts available.

Hydraulic System

Hydraulic Oil petroleum based lubricating oil. Most synthetic oils are acceptable. 100 to

300 SUS at operating temperature is recommended. Contact Woodward if in

doubt.

Operating Temperature continuous operating temperature is 140 to 200 °F (60 to 93 °C). Ambient

temperature is -20 to +210 °F (-29 to +99 °C). Hydraulic fluid pour point

must be below lowest expected starting temperature.

Operating Pressure 200 psi (1379 kPa) for EGB-200P. 360 psi (2482 kPa) for EGB-300P.

Sump Capacity 7.4 quarts (7.0 L)

Transducer Coil

Control Current 20–16 mA control signal at 400 mA maximum

Electrical Connector 10 pin connector, RB-3102-18-1P standard. Other connectors available.

Control Characteristics

Steady State Speed Band ±0.25% of rated speed

Droop in the ballhead section, droop is adjustable 0% to 12% through the full

terminal shaft travel

Construction

Case and Base cast iron

Column cast aluminum column

Weight 335 lbs (152 kg) with no oil in sump

Mounting

Configuration vertical

Options

Ballhead Assemblies solid (standard) or spring driven-oil damped. Available in undamped natural

frequencies of 180, 290, 400, 550 cpm

Solenoid Valve Shutdown the optional solenoid valve can be used for prime-mover shutdown.

Energize or de-energize to shutdown versions are available.

Speed Adjusting Motor permits remote, electric speed adjustment of the ballhead governor. The

motor is series wound, split field and available in most standard voltages. Optional switch contacts are useful for maximum and minimum indicator

lights and/or motor limit switches.

Oil Heat Exchanger an external heat exchanger may be used with the EGB-200P/-300P if high

ambient temperatures or high drive speeds cause oil operating temperatures greater than the oil manufacturer's temperature

recommendation.

Pneumatic, Manual Starting Devices

a pneumatic or manually operated plunger lowers the actuator pilot valve in the increase direction so the prime mover can start. Oil pressure generated at cranking speed is allowed to move the terminal shaft in the increase direction so the prime mover can start.

Booster Servomotor

pressure oil from the booster moves the servo piston to the maximum fuel position. The booster servomotor is detached from the EGB-200P/-300P and is actuated by a starting air pressure of 150 to 200 psi (1034 to 1379 kPa).


References

Woodward Manual


36641 Governor Oil Heat Exchanger, Remote and Integral Types

25071 Oils for Hydraulic Controls

82462 EGB-200/300P Proportional Governor/Actuator



Schematic Diagram, EGB-200P/-300P Governor/Actuator



Outline Drawing of EGB-200P

(Do not use for construction)



PO Box 1519, Fort Collins CO, USA 80522-1519 1000 East Drake Road, Fort Collins CO 80525 Tel.: +1 (970) 482-5811 • Fax: +1 (970) 498-3058 www.woodward.com

Distributors & Service

Woodward has an international network of distributors and service facilities. For your nearest representative, call the Fort Collins plant or see the Worldwide Directory on our website.

This document is distributed for informational purposes only. It is not to be construed as creating or becoming part of any Woodward contractual or warranty obligation unless expressly stated in a written sales contract.

Copyright © Woodward 1983-2001, All Rights Reserved

For more information contact: